



Energizer® Energi To Go™ Instant Cell Phone Charger Instructions (Double Cell)

1. Squeeze the dark gray buttons at bottom of the charger unit to release cover and gain access to the battery cavity area.
2. Locate battery diagrams on inside body of the charger and insert batteries facing opposite directions as indicated by the battery diagrams.
3. Squeeze bottom cover piece and reattach it to the charger unit.
4. Connect the phone-specific connector to the charger unit.
5. Connect your cell phone to the phone specific connector.
 - Unit will begin flashing within 10 seconds
 - If the unit does not flash, check the connection or insert a new battery.
6. Your phone should indicate that it is charging.
 - The unit will stop flashing when the charging process is complete.
 - For best results, do not leave the charger connected to the phone overnight.
7. To stop charging, remove the connector from the phone.
 - Charger unit will stop flashing within 70 seconds.
8. Charger may become warm during charging process. This is normal.

For maximum charge time, use Energizer® e2® Lithium batteries.

For best results:

- Charge your phone before its battery becomes fully exhausted.
- Do not mix new and old batteries.
- Do not mix battery chemistries.
- Remove batteries from the charger when not in use for extended periods of time.
- Do not store batteries in this charger.

Caution: Leave charger disconnected at least 10 minutes before changing batteries.



Energizer Holdings, Inc.
St. Louis, MO 63141